
Dimension Guide

Bottom freezer refrigerator

Model: EBE5307C-S (CN)



Total depth Cabinet Cabinet Bottom freezer refrigerator Door width Maximum Depth door Cabinet models: (W) (D) height (H) width (W1) depth (D1) open (D2) height (H1) EBE5307C-S (CN) 796 773 1725 790 641 1457 1705

Important! Please ensure that the access to your kitchen (including doorways, corridors, island benches, etc) allows sufficient clearance to move your fridge into position. Please note! Dimensions to be used as a guide only. All customers MUST refer to the user manual supplied with the product for detailed installation instructions. © 2020 Electrolux S.E.A PTE. LTD. E_DIM_EBE5307C-S_(CN)_Nov20

If you have a cupboard above the refrigerator with a rear gap of less than 100 mm (Y), recommended minimum clearance at the top of the refrigerator increases from 50mm to 90mm (X).

Please note: Doors are designed to sit proud of cabinetry (not flush).

When positioned in a corner area, spacing of at least 350mm on the hinge side will allow the doors to open enough to enable the removal of bins

